

THE COLISEUM



TM



# RIDER

ROCKWELL

THE  
COLISEUM

RIDER BY ROCKWELL WAS DEVELOPED FOR INDIVIDUALS WHO WANT TO MAKE A STATEMENT ABOUT THEIR ACTIVE LIFESTYLE. THIS PIECE EMBODIES THE PHILOSOPHY, "FORM FOLLOWS FUNCTION". IN THAT THE COLISEUM WAS DESIGNED NOT ONLY TO PERFORM IN ALL ATMOSPHERES, BUT ALSO TO LOOK SUPER SICK WHILE RIDING UPON ONES WRIST. THAT BEING SAID, STRAP THIS BAD BOY ON AND TAKE ER' FOR A RIDE!



# RIDER



ROCKWELL

## TABLE OF CONTENTS

REGULAR DISPLAY _____	PG. 1-2
SETTING TIME _____	PG. 3-4
CHRONOGRAPH/LAP SPLIT TIME _____	PG. 5-6
SPLIT OR LAP OPERATION _____	PG. 7-8
HOW TO USE RECALL _____	PG. 9-10
HOW TO USE TIMER _____	PG. 11-12
SET DAILY ALARM _____	PG. 13-14
SET DATE ALARM TIME _____	PG. 15-16
TIME ZONE/HOURLY CHIME _____	PG. 17-18
LIGHT/SOUND _____	PG. 19-20
WATCH CARE/FEATURES _____	PG. 21-22



## REGULAR DISPLAY AND BUTTON OPERATION

E-01




### BUTTON OPERATION

- |                     |                                   |
|---------------------|-----------------------------------|
| <b>A</b> SET/RECALL | <b>C</b> ADVANCE/START/SPLIT/LAP  |
| <b>B</b> MODE       | <b>D</b> RECEDE/STOP/ADJUST/LIGHT |


## HOW TO CHANGE THE DISPLAY MODE

E-02



## HOW TO DISPLAY CALENDAR

E-03





## HOW TO SET NORMAL TIME

E-05



MONTHS



DATE



12 HR FORMAT



ENABLE BUTTON TONE



ADVANCE MONTH

SET MONTHS



ADVANCE DATE

SET DATE



24 HR FORMAT

SET 12/24  
FORMAT



DISABLE BUTTON TONE

SET BUTTON TONE  
(ON/OFF)

### SET SECONDS


- Minutes do not advance and seconds return to zero when set seconds before 30 seconds.
- Minutes advance and seconds return to zero when set seconds after 30 seconds.

- Press "D" to advance the setting. Hold "C" for longer time than 2 seconds can advance the setting rapidly.
- Press "B" to reverse the setting.

Return to normal time display, the week will be set automatically


## HOW TO USE THE CHRONOGRAPH

E-06



## HOW TO CHANGE THE LAP/SPLIT MODE

E-07



## HOW TO SET THE SPLIT OR LAP OPERATION

E-08



NORMAL TIME



CHRONOGRAPH



START



STOP

Switch mode, refer to page 7

LAP / SPLIT MODE



FIRST LAP  
This screen is  
shown for 0.8 sec



SECOND LAP  
This screen is  
shown for 0.8 sec




STOP  
THIRD LAP



CONTINUE


## HOW TO SET THE SPLIT OR LAP OPERATION

E-09




## HOW TO USE THE RECALL

E-10




## HOW TO USE THE RECALL

E-11



## HOW TO USE TIMER

E-12



## HOW TO USE TIMER

E-13




During the last 10 seconds of the countdown, the alarm will beep (B) once per second.




## HOW TO SET DAILY ALARM TIME

E-14



## HOW TO SET DAILY ALARM TIME

E-15



## HOW TO SET DATE ALARM TIME

E-16



NORMAL TIME



B x3



C x4

**ALARM 5**  
No button is pressed  
(this screen is shown  
for 0.8 sec)



ALARM OFF



ALARM ON



HOLD FOR 3 SECONDS

- Press "C" to advance the setting. Hold "C" for longer time than 2 seconds can advance the setting rapidly.
- Press "B" to reverse the setting.

## HOW TO SET DATE ALARM TIME

E-17

DATE ALARM  
(5TH - 8TH ALARM)

When you enter Settings, alarm automatically turns on.



MONTHS



DATE



HOURS



MINUTES



ADVANCE MONTH



ADVANCE DATE



+1 HOUR



+1 MINUTE

## HOW TO SET SECOND TIME ZONE

E-18



NORMAL TIME



B

x4

SECOND TIME ZONE



HOURS



+1 HOUR



HOLD FOR 3 SECONDS



MINUTES



30 MINUTES

■ Press "C" to advance the setting. Hold "C" for longer time than 2 seconds can advance the setting rapidly.

■ Press "D" to reverse the setting.

## HOW TO SETUP HOURLY CHIME ON/OFF

E-19




NORMAL TIME



CHIME OFF



CHIME ON

**NOTE:**

1. This watch features an electro-luminescent (EL) backlight, which tends to lose illuminating power after very long use.
2. The illumination provided by backlight may be hard to see under direct sunlight.

1. **Button tone:** Turn ON or OFF, see "How to set function display."
2. **Beeps with each press of a button except for the LIGHT button .**
3. **The button will only beep once when pressed and held**
4. **Alarm duration: 20 sec, two short beeps per second, beep once every hour.**
5. **The TIMER sound will take priority over the ALARM sound**

## CARE OF YOUR WATCH

E-22

1. This watch contains precise electronic components. Never attempt to open the case or remove the back cover.
2. Do not operate buttons while underwater, or while swimming or diving.
3. Should water or condensation appear in the watch, immediately have the watch checked. Water can corrode electronic parts inside the case.
4. Avoid severe impact: The watch is designed to withstand impact under normal use. Do not subject it to severe impacts or rough usage, and do not drop it onto hard surfaces.
5. Avoid exposing the watch to temperature extremes.
6. Clean the watch with a soft cloth and clean water only. Avoid using chemicals, especially soap.
7. Keep your watch away from strong electric fields and static electricity.

## FEATURES AND SPECIFICATIONS

E-23

1. Standard display mode: Hour, Minutes, Seconds, Day of the week, Month, Date.
2. Function:
  - \* 100-hour chronograph with memory for 50 laps / splits, and average lap.
  - \* 24-hour countdown timer.
  - \* 8 alarm (4 daily / 4 date) function with buzzer signal output.
  - \* Second time zone.
  - \* Hourly chime.
  - \* Perpetual calendar.
  - \* 12/24 hour format switch option .
  - \* AM / PM & Electro-Luminescent light.
  - \* Button tone ON/OFF function
3. Accuracy at normal temperature (25°C):  $\pm 30$  seconds a month.
4. Normal operating temperature range: 10°C ~ 40°C.

THE COLISEUM



TM